# User Manual M5-1C/2C/3C-86W(EN)



SwitchMan Smart Wall Switch

## Introduction

This device is a smart physical wall switch. After pairing it with eWeLink App, you can turn on/off the connnected devices via the smart phone wherever you are, schedule its on/off, share it with your families to control together, etc.











Remote Control

Single/Countdown **Timing** 

Voice Control

Share Control

Smart Scene











Inching Mode

Camera Linking

**Group Control** 


**History Operation** 

LAN Control

#### Record

#### 1) Button

- Press once: Turn on/off the Device.
- Press and hold for 5 seconds : Device enters the pairing mode.



#### 2 Wi-Fi LED indicator (Blue)

#### eWeLink Mode

- Keeps on: Device is online.
- Flashes twice: LAN
- Flashes once: Offline (2602432)
- Flashes two short and one long: Device is in pairing mode.

#### Matter Mode

- Keeps on: Device is online.
- Flashes once: Offline
- Flashes two short and one long: Device is in pairing mode.
- Flashes three times: Identify

# Matter-compatible ecosystem








# **Specification**

Model	M5-1C-86W, M5-2C-86W, M5-3C-86W			
MCU	ESP32			
	1C: 100-240V ~ 50/60Hz 10A Max			
Rating	2C: 100-240V ~ 50/60Hz 5A/Gang 10A Total Max			
	3C: 100-240V ~ 50/60Hz 2A/Gang 6A Total Max			
	1C: 2200W			
Max. load	2C: 2200W(1–1100W/Gang)			
	3C: 1320W(1-440W/Gang)			
LED load	1C: 300W/220V, 150W/110V			
	2C: 300W/220V/Gang, 150W/110V/Gang			
	3C: 100W/220V/Gang, 60W/110V/Gang			
Wireless Connectivity	IEEE 802.11 b/g/n 2.4GHz			
Net Weight	1C(153.8g) 、 2C(160g) 、 3C(163.7g)			
Dimension	86x86x41.5mm			
Color	White			
Casing Material	PC V0+CRS			
Applicable Place	Indoor			
Working Temperature	ture -10°C~40°C			
Working Humidity	5%~95% RH, non-condensing			
Certified Compliance	CE/CQC/RoHS			
Executive standard	Executive standard EN 60669-2-1			

# Installation


1. Power off







\*Please install and maintain the device by a professional electrician. To avoid electric shock hazard, do not operate any connection or contact the terminal connector while the device is powered on!

#### 2. Wiring instruction








\*To ensure the safety of your electrical installation, it's essential either a Miniature Circuit Breaker (MCB) or a Residual Current Operated Circuit Breaker (RCBO) with an electrical rating of 10A (1C,2C),6A (3C)has been installed before the M5-86W.

<sup>\*</sup>Make sure all wires are connected correctly.

# 3. Power on

After powering on, the device will enter the Pairing Mode defaulted during the first use, and the LED indicator flashes in a cycle of two short and one long.



\*The device will exit the Pairing Mode if it is not paired within 10mins. If you want to enter this mode again, please long press the button for 5s until the LED indicator flashes in a cycle of two short and one long and then release.

## Add device

## Method 1: Matter Pairing

Open a Matter-compatible App (e.g. Alexa App, Google Home App, or Apple Home App, etc) to scan the Matter QR code on the Quick Guide or the device itself to add the device.



Add to Alexa via Matter



Add to Google via Matter




Add to Apple via Matter

## Method 2: eWeLink App Pairing


## 1.Download the "eWeLink" App

Please download the "eWeLink" App from Google Play Store or Apple App Store.






#### 2.Add device




Enter"Scan"




Scan the QR code on the device









Please follow the wiring instructions to connect the wires (ensure power is disconnected in advance and consult an electrician if needed)



Power on the device



Long press the button for 5 seconds



Check Wi-Fi LED indicator flashing status (Two short and one long)






Select"Add Device"



Search for the device and start connecting



Select the "Wi-Fi" network and enter the password.



Device"Added completely".

# **Device Network Changing**

Change the device's network by "Wi-Fi Settings" in the "Device Settings" page on the eWeLink App.

# Device Factory Reset (Dual Ecosystem)

- After "Delete the Device" in the eWeLink App
- For devices previously successfully added to eWeLink, perform a new pairing using a different eWeLink account

 For devices previously successfully added in Matter, perform a new Bluetooth Pairing through Matter

# FAQ (2602432)

#### Fail to pair Wi-Fi devices with eWeLink APP

1. Make sure the device is in pairing mode.

The device will automatically exit the pairing mode if not paired within 10mins.

2. Please turn on the location service on your mobile phone and give the permission.

Before choosing the Wi-Fi network, the location service should be turned on and the permission is given. Location information permission is used to obtain Wi-Fi list information. If you tap "Disable", the device will not be added.

- 3. Make sure your Wi-Fi network runs on the 2.4GHz band.
- 4. Make sure you entered a correct Wi-Fi SSID and password, no special characters contained. A wrong password is a very common reason for pairing failure.
- 5. You may get the device close to the router for a good signal transmission while pairing.
- 6. Please try to pair the device in the compatible mode.

#### Wi-Fi devices "Offline" issues

Please check the following issues by the Wi–Fi LED indicator status:

ITEAD -黎业军(2602432) The LED indicator blinks once every 2s means you fail to connect to the router.

- 1. Maybe you entered a wrong Wi-Fi SSID and password.
- 2. Make sure your Wi-Fi SSID and password don't contain special characters, for example, the Hebrew, Arabic characters. Our system can't recognize these characters so that fail to connect to the Wi-Fi.
- 3. Maybe your router has a lower carrying capacity.
- 4. Maybe the Wi-Fi signal strength is weak. Your router is too far away from your device, or there may be some obstacles between the router and the device so that the signal transmission is blocked.
  - 5. Be sure that the MAC of the device is not on the blacklist of your MAC management.

#### The LED indicator flashes twice on repeated means you fail to connect to the server.

- 1. Make sure the Internet connection is normal. You can use your phone or PC to connect to the Internet, and if you fail to access, please check the availability of the Internet connection.
- 2. Maybe your router has a low carrying capacity. The number of devices connected to the router exceeds its maximum value. Please check the maximum number of devices that your router can carry. If the number of connected devices exceeds the maximum value, please delete some devices or change a lager router and try again.
- ...u: (TEAD 黎业军(2602432) 3. Please contact your ISP and confirm our server address is not shielded:

cn-disp.coolkit.cc (China Mainland)

as-disp.coolkit.cc (in Asia except China)

eu-disp.coolkit.cc (in EU)

us-disp.coolkit.cc (in US)

If none of the above methods solved this problem, please submit your issue via help&feedback ITEAD - 黎业军 on the eWeLink App.

# **SAR Warning**

Under normal use of condition, this equipment should be kept a separation distance of at least 20 cm between the antenna and the body of the user.

Dans des conditions normales d'utilisation, cet équipement doit être maintenu à une distance d'au moins 20 cm entre l'antenne et le corps de l'utilisateur.

# **WEEE Warning**



WEEE Disposal and Recycling Information All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted householdwaste. Instead, you should protect human health and the environment by handingover your waste equipment to a designated collection point for the recycling of waste electricaland electronic equipment, appointed by the government or local authorities. Correct disposaland recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about thelocation as well as terms and conditions of such collection points.

# **EU Declaration of Conformity**

Hereby, Shenzhen Sonoff Technologies Co., Ltd declares that the radio equipment type [M5–1C–86W, M5–2C–86W, M5–3C–86W] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

https://sonoff.tech/compliance/

Scatola	Scatola	Manuale	Borsa	Borsa
PAP 20	PAP 21	PAP 22	CPE 7	LDPE 4
Carta	Carta	Carta	Plastica	Plastica

#### RACCOLTA DIFFERENZIATA

Verifica le disposizioni del tuo Comune.

Separa le componenti e conferiscile in modo corretto.



Manufacturer: Shenzhen Sonoff Technologies Co., Ltd.

Address: 3F & 6F, Bldg A, No. 663, Bulong Rd, Shenzhen, Guangdong, China

ZIP code: 518000 Service email: support@itead.cc

Website: sonoff.tech Made in China



























